©Copyright 1992, Xandex Inc., All Rights Reserved. The information disclosed herein is deemed to be									
confidential, proprietary, and a trade secret of Xandex, Inc.  This information may not be used, reproduced or disclosed without the expressed prior written consent of Xandex, Inc.	REV	DESCRIPTION	ECO	BY	DATE	APPROVED			
minute the expressed pro- written consent of names, me.	Α	INITIAL RELEASE	564	JT	3/18/93				

## NOTES:

- INKER IS DESIGNED FOR USE ON TRILLIUM MICROMASTER AND DELTA-MASTER TEST HEADS. TEST HEAD MUST BE OUTFITTED WITH THE BLACK PLASTIC GUARD (TRILLIUM PART NUMBER A-530419-01).
- 2. FOR 1" POGO STACKS, ORDER INKER KIT X3100 (PART NUMBER 340-3100). FOR 1.5" POGO STACKS, ORDER INKER KIT X3110 (PART NUMBER 340-3110). FOR KLA VERSIONS USING 1.5" POGO STACKS, ORDER INKER KIT X3200 (PART NUMBER 340-3200). INKERS CAN BE ADAPTED TO 1" OR 1.5" POGO STACKS BY CHANGING THE CARTRIDGE HOLDER MOUNTING ARMS. FOR CONVERSION FROM 1" TO 1.5", ORDER ARM 120-0030. FOR CONVERSION FROM 1.5" TO 1", ORDER ARM 120-0029.
- 3. X, Y ADJUSTMENT IS ±.062. Z ADJUSTMENT CAPABILITY IS ±.125 PLUS AN ADDITIONAL .10 ADJUSTMENT TO ACCOMODATE PROBE TIPS LONGER THAN .080.
- 4. INKER CAN BE USED WITH EITHER:
  THE OLYMPUS SZ SERIES MICROSCOPE WITH A 0.3X OR 0.4X OBJECTIVE
  LENS. MINIMUM WORKING DISTANCE IS 210mm (8.27").
  OR:

THE OPTEM HF-65 MICROSCOPE WITH A 0.7X-4.5X OBJECTIVE LENS. MINIMUM WORKING DISTANCE IS 90mm (3.50").

FILE NAME 9000146A	ITEM QTY PART NUMBER			DESCRIPTION						
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON: 2 PL DECIMALS ±	SIGNATURE DRAWN J. TEMPLE CHECKED		•	XA	NDE	INC.	PETALL	. McDOWE JMA, CA 9 763 7799	95954	
3 PL DECIMALS ± ANGLES ± FRACTIONS ± MATERIAL:	ISSUED NEXT ASSY'S		""" INKER SERIES 3000, REMOTE ADJUST PNEUMATIC							
HEAT TREAT OR PLATING			size A	FSCM NO		DWG NO	900-	-014	6	REV A
			SCALE	1/2			s	HEET 1	of 2	

